




PERLESMITH

Table Top TV Stand Instruction Manual

V8.0 (B)



Model: PSTVS01-1

Thank you for choosing our product! We strive to provide the best quality and services for our customers. For any parts inquiries, please contact AV Supply Group as below:


New Zealand: New Zealand P 64 9 2749172 E info@avsupply.co.nz

Australia: P 61 3 9071 4585 E info@avsupplygroup.com.au


IMPORTANT SAFETY INFORMATION

- Please read through these instructions completely before attempting installation. If you do not understand the instructions or have any concerns or questions, please contact customer service.
- Check package contents against Supplied Parts and Hardware List to assure that all components were received undamaged. Do not use damaged or defective parts. If you require replacement parts, contact customer service.
- Not all parts and hardware included will be used.
- Do not use this product for any purpose or in any configuration not explicitly specified in this instruction. We hereby disclaim any liability for injury or damage arising from incorrect assembly or incorrect use of this product.


Supplied Parts and Hardware




A1 x1
Left Base Plate




A2 x1
Left Junction Plate



A3 x1
Left TV Bracket




A4 x1
Left TV Bracket




B1 x1
Right Base Plate



B2 x1
Right Junction Plate



B3 x1
Right TV Bracket




B4 x1
Right TV Bracket




C x8
M6x10 Bolt



D x4
M6 Nut



E x1
Allen Key



F x1
Wrench


Hardware for Attaching TV Brackets to TV



G1 x4
M4x12 Bolt




G2 x4
M4x30 Bolt




H1 x4
M6x15 Bolt




H2 x4
M6x35 Bolt



I1 x4
M8x15 Bolt



I2 x4
M8x35 Bolt



I3 x4
M8x50 Bolt



J x4
M4/M5 Washer



K x4
M6/M8 Washer



L x4
L10mm Spacer




M x8
L2.5mm Spacer




N x4
L22mm Spacer


Step 1 Connect the Base Plates to Junction Plates



Step 2 Connect the TV Brackets



Step 3 Secure the Bracket on the Holder According to Your Height Choice




There are two choices of height adjustment. You can choose the appropriate height choice while securing the TV bracket on the holder.

Step 4 Secure the TV Brackets on TV

Bolt length: Verify adequate thread engagement with bolts or bolts/spacers combination.
 -Too short will not hold the TV.
 -Too long will damage the TV.



Option A (For Flat Back TV)



Option B (For Round Back TV)

