SPECIFICATION

Transmitter

Input Port Output Port 1 x HDMI (Female Connector) 1 x IR Channel, 2 x Cat5e/6/7

Receiver Input Port Output Port

1 x IR Channel, 2 x Cat5e/6/7 1 x HDMI (Female Connector)

Bandwidth Output Resolution Operating Temperature Deep Color Chassis Dimension Weight Power Supply

6.75Gbps 480i~1080P@50/60,1080P@24/50/60, VGA~UXGA -15 C~55 C/5°F~131°F 36bit Metal 83mm(L)x46mm(W)x22mm(H) 215g DC 5V

SAFETY PRECAUTIONS

Please read the following safety precautions carefully before you unpack and install this equipment.

CAUTION: Do not use this product for any purpose not explicitly specified by AVS. Improper installation may cause property damage or personal injury. If you do not understand these directions, or have doubts about the safety of the installation, contact AVS Customer Service or call a qualified contractor. AVS is not responsible for damage or injury caused by incorrect mounting, assembly, or use.

 Do not expose the unit to rain, moisture or any other dripping liquids. And keep it away from any wet locations such as fishing tanks, vases.
 Do not install the unit close to fire or any other heat sources.
 Keep the unit in dry and ventilated area. Do not install in bookcase, cabinet or any other confined space. 4.Stop using the unit during thunder or lightening storms.
5.Avoid the power cable being stepped on or pinched. Position the unit carefully to avoid damage or accident.
6.Clean the unit only with dry cloth.
7.Only use accessories specified by the manufacturer.
8.Unplug the equipment when unused for a long period of time.
9.Do not try to open any non-serviceable parts. Contact your authorized servicing center and personnel.

WARNING! This product contains small items that could be a choking hazard if swallowed. Keep these items away from young children!

AV Supply Group (AVS) intend to make this manual accurate and complete. However, AVS makes no claim that the information contained herein covers all details, conditions, or variations. Nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. AVS makes no representation of warranty, expressed or implied, regarding the information contained herein. AVS assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.





AV SUPPLY GROUP LTD

 Address:
 Phone: (09) 274 9172

 2/6 Ormiston Road
 Fax: (09) 274 8363

 Flat Bush
 Email: info@avsupply.co.nz

 Auckland 2016
 www.avsupply.co.nz

Full 3D Pass-through Support IR Control 50M Solution



THEATRE

HDMI Extender Over 2 x Cat5e/6/7

User Manual



INTRODUCTION

This HDMI extender by Cat.5e/6/7 uses 2X Cat.5e/6/7 cables to extend the HDTV display up to 50M for 1080P. It is equipped with HDMI connector and is capable of supporting DVI equipment when used with an HDMI to DVI adaptor. And if that weren't enough, you can use a remote to control your device from over 50m away through an IR blaster and receiver pigtail.

It follows the standard of IEEE-568b, Cat.5e/6 cable can substitute HDMI cable to achieve long distance transmission. It is designed for use in home theater, professional A/V and personal computer switching applications.

PACKAGE CONTENTS

•1 x HDMI Transmitter unit, 1x HDMI Receiver unit

•1 x 5V DC power supply •1 x User Manual

FEATURES

HDMI, HDCP 1.2 and DVI compliant
Support full 3D pass-through
Support high resolution up to 1080P
Super IR control system, IR transport channel can be forward or backward per your installation
Extend to 50M over 2 x Cat5e/6/7
Support CEC bypass
External and internal EDID settings


PANEL DESCRIPTION

Transmitter Unit



HDMI INPUT
IR OUTPUT
CAT5E/6/7 OUTPUT

Receiver Unit



① CAT5E/6/7 INPUT
② IR INPUT
③ HDMI OUTPUT
④ POWER SUPPLY INPUT

INSTALLATION

•Connect HDMI input port on transmitter to the signal source equipment such as DVD player.

•Connect the 2x CAT5e/6/7 output of the transmitter with 2 CAT5e/6/7 cables to the CAT5e/6/7 inputs of the receiver.

•Connect to the IR blaster cable (not included in the package) for IR signal transmission. Place the IR blaster in direct line-of-sight of the equipment to be controlled.

•Connect HDMI output port on receiver to HDMI displays. •Connect to the IR receiver cable (not included in the package) for IR signal reception. Make sure that the remote being used is in direct line-of-sight of the IR receiver.

•Plug the 5VDC power supply into the unit and connect the adaptor to AC outlet.

CONNECTION DIAGRAM

